



First step is to insert the unprimed shell in the Lanes priming tool



second step set primer on the primer pocket. You can also set the primer on a flat surface and start the primer by pushing the shell on the the primer.

## Lane's Priming Tool

Third step close Lanes priming tool squeeze the open end till they come together. Now you can remove your primed shell from the tool.

